

3 PHASE DIODE BRIDGE

| | | | | | | | | | | | | | | | | | |
|----------------------|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|
| | 1 | 2 | 3 | 4 | 5 | 6 | | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| ORDERING CODE | B | D | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |

| CURRENT | 3 | 4 | 5 | 6 | |
|---------------------|------|---|---|---|------|
| description | code | | | | note |
| 2000A | 2 | 0 | 0 | 0 | |
| 2300A | 2 | 3 | 0 | 0 | |
| 3000A | 3 | 0 | 0 | 0 | |
| 3500A | 3 | 5 | 0 | 0 | |
| 4000A | 4 | 0 | 0 | 0 | |
| MAX VOLTAGE | 7 | | | | |
| description | code | | | | note |
| 480V | 4 | | | | |
| 600V | 6 | | | | |
| 690V | 7 | | | | |
| VOLTAGE SUPPLY AUX. | 8 | | | | |
| description | code | | | | note |
| 110V | 1 | | | | |
| 220V | 2 | | | | |
| INPUT | 9 | | | | |
| description | code | | | | note |
| No Input | 0 | | | | |
| FIRING | 10 | | | | |
| description | code | | | | note |
| None | 0 | | | | |
| CONTROL MODE | 11 | | | | |
| description | code | | | | note |
| None | 0 | | | | |

| OPTION & FUSES | 12 | |
|----------------------|------|------|
| description | code | note |
| Fixed fuses standard | F | |
| Fixed fuses + CT | Y | |
| FAN VOLTAGE | 13 | |
| description | code | note |
| Fan 110V | 1 | |
| Fan 220V Standard | 2 | |
| APPROVALS | 14 | |
| description | code | note |
| CE EMC | 0 | |
| MANUAL | 15 | |
| description | code | note |
| None | 0 | |
| Italian | 1 | |
| English | 2 | |
| German | 3 | |
| French | 4 | |
| LOAD TYPE | 16 | |
| description | code | note |
| Resistive Load | 1 | |
| Inductive Load | 2 | |